





SLW WEATHER STATION
(SEE LEGEND FOR MODEL)
SYNCHRONIZE TO WEATHER
STATION HUB IN CONTROLLER



SmartWire Controller in SLWMSS WIRE TO DECODER 97/98

Enclosure with SLW & Aircard with Flow

00

NTS

DETAIL-FILE