




RFS RAIN/FREEZE SENSOR  
(SEE LEGEND FOR MODEL)  
SYNCHRONIZE TO HUB IN  
CONTROLLER



WALL

PL SERIES CONTROLLER  
(SEE LEGEND FOR MODEL)



CONDUIT 115V A.C.

CONDUIT 24V A.C.

FINISH GRADE

POWER SUPPLY  
WIRES

TO MASTER VALVE  
(OPTIONAL)

#8 BARE COPPER  
GROUND WIRE TO  
GROUND GRID

VALVE CONTROL WIRES  
(ONE PER VALVE)

00

### ProLine Controller with RFS

NTS

DETAIL-FILE