





RFS RAIN/FREEZE SENSOR
(SEE LEGEND FOR MODEL)
SYNCHRONIZE TO HUB IN
CONTROLLER



WALL



ProLine Controller in SLWM Cabinet with RFS & Aircard

00

NTS

DETAIL-FILE