





RFS RAIN/FREEZE SENSOR
(SEE LEGEND FOR MODEL)
SYNCHRONIZE TO HUB IN
CONTROLLER



← WALL →



ProLine Controller in SLWM Cabinet with RFS & Aircard with Flow

00

NTS

DETAIL-FILE