





SLW WEATHER STATION
(SEE LEGEND FOR MODEL)
SYNCHRONIZE TO WEATHER
STATION HUB IN CONTROLLER



SmartLine Controller in SLWM Cabinet with SLW & Aircard with Flow

00

NTS

DETAIL-FILE