





SLW WEATHER STATION
(SEE LEGEND FOR MODEL)
SYNCHRONIZE TO WEATHER
STATION HUB IN CONTROLLER



WALL



00

SmartWire Controller in SLWMSS Enclosure with SLW

NTS

DETAIL-FILE