





SLW WEATHER STATION  
(SEE LEGEND FOR MODEL)  
SYNCHRONIZE TO WEATHER  
STATION HUB IN CONTROLLER.



## SmartWire Controller in SLPED-ENC Enclosure with SLW & Aircard

00

NTS

DETAIL-FILE