





SLW WEATHER STATION
 (SEE LEGEND FOR MODEL)
 SYNCHRONIZE TO WEATHER
 STATION HUB IN CONTROLLER.



**SmartWire Controller in SLPED-ENC
 Enclosure with SLW & Aircard with Flow**

00

NTS

DETAIL-FILE