





SLW WEATHER STATION  
(SEE LEGEND FOR MODEL)  
SYNCHRONIZE TO WEATHER  
STATION HUB IN CONTROLLER



00

## SmartWire Controller with SLW

NTS

DETAIL-FILE