





SLW WEATHER STATION
(SEE LEGEND FOR MODEL)
SYNCHRONIZE TO WEATHER
STATION HUB IN CONTROLLER



00

SmartWire Controller with SLW & Aircard

NTS

DETAIL-FILE