





SLW WEATHER STATION  
(SEE LEGEND FOR MODEL)  
SYNCHRONIZE TO WEATHER  
STATION HUB IN CONTROLLER



### SmartWire Controller in SLWMSS Enclosure with SLW & Aircard

00

NTS

DETAIL-FILE